CONTROL PANEL PARTS

For Model: SF365BEYQ4

(Designer White)

30" GAS
FREESTANDING RANGE
ELECTRONIC IGNITION
SELF− CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
1	4371679	Panel, Control
2	4371675	Clock, Timer
3	4371538	Bracket, Timer
4	4371316	Endcap, RH
5	4371317	Endcap, LH
6	4371563	Cap, Filler
7	4371320	Retainer, Timer
8	4371674	Trim, Wrapper
9	4371562	Trim, Deflector
10		Support,Backguard
	4372307	RH.
	4372308	LH.
11	4371524	Shield, Rear Wall
12	4371537	Deflector, Flue
13	4371568	Knob, Clock(3)
14	4371626	Light,Indicator(2)
15	4372285	Lens, Ind Light(3)
16	4371627	Light, Indicator
17	4371629	Switch, Selector
18	4371630	Thermostat
19	4371676	Knob, Selector
20	4371677	Knob, Thermostat
21	4371655	Shield,Inner Bkgd

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Model: SF365BEYQ4

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	4372211	Grate (4)
2	4371547	Top, Main
3	4371545	Bracket, Hinge RH
4	4371546	Bracket, Hinge LH
5	4371673	Panel, Manifold
6	4371685	Knob, Control (4)
7	4372341	Rod, Support Top
8	4371565	Pan, Burner (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Model: SF365BEYQ4
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	4372225	Burner, Double (2)
2	4371021	Tubing, Burner(RF)
3	4371023	Tubing, Burner(RR)
4	4371022	Tubing, Burner(LF)
5	4371024	Tubing, Burner(LR)
6	4372306	Pipe, Manifold
7	4371504	Valve, Top(4)
8	4371019	Bracket,Burner Mtg
9	4371164	Switch, Ignitor(4)
10	4372316	Tubing, Regulator To Manifold Pipe
11	4372040	Control, Regulator
12	816636	Bracket, Regulator
13	4371017	Ignitor,Top Burner
14	4371027	Screw, Burner Mtg.
15	4371029	Nut, Special(4)
16	4371242	Retainer, Ignitor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BROILER & OVEN BURNER PARTS

For Model: SF365BEYQ4
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	816582	Baffle, Broiler Burner
2	816584	Baffle, Oven Burner
3	816722	Burner, Broiler
4	816588	Burner, Oven
5	816624	Ignitor, Broiler Burner
6	816625	Ignitor, Oven Burner
7	4371030	Ignitor, Module
8	816594	Mixer, Elbow
9	4372314	Tubing, Valve To Mixing Elbow
10	816692	Valve, Safety
11	4372315	Tubing, Valve To Regulator
12	816642	Nut, Hex (2)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: SF365BEYQ4

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: SF365BEYQ4

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	816669	Spacer, Body (8)
2	816659	Shield, Rear Wall
3	816651	Screw, Oven Bottom
4	816668	Socket, Oven Lamp
5	4371303	Bulb, Oven Light
6	4371621	Retainer, Lens
7	816609	Lens, Oven Light
8	4371087	Hinge, Oven Door
9	816617	Cover, Hinge
10	4371042	Shield, Heat (Upper)
11	816657	Shield, Heat (Lower)
12	816614	Cord, Power
13	816640	Switch, Latch
14	816633	Fastener, Push−On
15	4371482	Clip, Thermo Bulb
16	4372290	Back, Main
17	4372288	Rod, Light
18	816608	Bumper, Front (2)
19	4371682	Cover, Rod End
20	4372289	Switch, Door
22	4371661	Shield, Rear Heat
23	816577	Clip, Wire
24	4371652	Flue Box
25	816620	Gasket, Flue
26	4371680	Knob, Latch
27	4371036	Latch, Door
28	4371151	Handle, Latch
29	816615	Cover, Plate
30	4371025	Burner Box
31	816776	Shield, Main Front
32	816638	Shield, Latch
33	816660	Shield, Heat Baffle
34		Panel, Side
	816709	LH.
	816708	RH.
35	4371909	Screw, Leveler (4)
36	4372313	Support, Oven Bottom
37	816618	Fastener, Cord
38	4372312	Insulation, Oven Back
39	4372245	Bottom, Oven
40	4371033	Fastener, U Type
41	816585	Bracket, Anti Tip
42	816639	Spacer, (2)
43	816637	Shield, Latch
44	816658	Shield, Oven Top
45	816648	Shield, Side(2)
46	816627	Insulation, Front
47	816629	Insulation, Oven Wrapper
48	4371664	Screw, Latch
49	816621	Glide, Drawer
50	4371662	Shield, Flue
51	816628	Insulation, Ov Top
52	816663	Shield, Wire
53	816664	Shield, Wool
54	4371527	Bracket,Maintop RH
55	4371528	Bracket,Maintop LH

OVEN RACK PARTS



Illus. No.	Part No.	DESCRIPTION
1	4371483	Rack, Oven(2)
2	816626	Insert, Broiler Pan
3	816644	Pan, Broiler

LITERATURE PARTS

LIT4372203	Guide, Use & Care
LIT4372195	Instructions, Installation

OVEN DOOR AND DRAWER PARTS

For Model: SF365BEYQ4

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	816736	Handle, Door
2	816746	Trim, Door
3	4371678	Glass, Door
4	4371074	Endcap (2)
8	4371609	Shield, Heat
12	816682	Insulation, Door
13	4371044	Liner, Oven Door
14	4371542	Screw, Handle
15	816685	Seal, Oven Door
16	816711	Drawer, Utility
17	816712	Guide, Drawer
18	4372318	Panel, Drawer
19	816753	Handle, Utility Drawer
20	816716	Shield, Panel
21	816713	Spacer, Handle
22	4371062	Screw, Drawer(5)
23	4371063	Screw, Handle(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST